



80/1163 Black

80/1466 White

Satco step-on button cord switch installation instructions

1. Slit wire 2 1/2" (figure 1).
2. Cut 3/4" notch on smooth wire (figure 1).
3. Strip wire 3/8" on both ends (figure 1).
4. Insert stripped end of wires into opposite sides of switch (figure 2).
5. Place switch with wires attached in base as shown (figure 3).
6. Attach 2 strain release clamps to base (figure 4).
7. Slide spring, cap and cover over switch and onto base.





Figure 2



Figure 3





Figure 4



Rating: 1A 250VAC / 2A 125VAC

