

65/1101 and TP240

Installation



Out of the box, one should look like this.



Remove the screw from the plunger with a Phillips head screwdriver



Insert the screw into the fixture body (there are two holes, one on either end.)



Attach the plunger into the backside of the fixture, and screw in the screw.