

## ASSEMBLY INSTRUCTION

**SKU:60/4931/4932/4933**

**NOTE:** Please consult a qualified electrician if you are not certain of the installation.

**CAUTION:** Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

1. Fasten the Cross Bar onto Outlet Box by using 2 Outlet Box Screws. (Make sure the thread of the mounting screws are facing outside when the Cross Bar is attached to the Outlet Box).
2. Using two pliers twist open the links at the two ends of the Chain. Hook one link to the Top Loop and the other link to the Bottom Loop. Close the links.
3. Weave the fixture wires up through the Bottom Loop, through the Chain, through the Top Loop, and through the canopy.
4. Connect the wire with writing on it to the black wire from the supply circuit. Connect the wire without writing on it to the white wire from the supply circuit. Cover the connections using Wire Connectors provided. Tie the ground wires from fixture and from Outlet Box to the Ground Screw on the Cross Bar. Position wires back inside Outlet Box.
5. Place Canopy to Outlet Box by aligning the protruding Mounting Screws all the way through the Canopy and tighten it using 2 Lock Nuts provided until it is held firmly to the ceiling.
6. Place the Fixture Frame onto the Top Cover, make sure the holes of the Top Cover and the Screws of the Fixture Frame are overlapped and fasten them by using the Lock Nuts.
7. Install the bulb. (Not included).
8. Turn on the power.

