

S19964 S19965 S19966 Ballast Compatible List			
--	--	--	--

No.	Ballast Brand	Model No.	Start Type	Max Loading QTY	Compatible (Y/N/N/A)							
					1 LAMP		2 LAMPS		3 LAMPS		4 LAMPS	
					120VAC	277VAC	120VAC	277VAC	120VAC	277VAC	120VAC	277VAC
1	PHILIPS ADVANCE	ICN-2S54-90C-T	Programmed Start	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A
2	PHILIPS ADVANCE	ICN-2S54-90C-N	Instant Start	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A
3	KEystone	KTEB-254HO-UV-PS-SL	Program Start	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A
4	OSRAM	QHE 2X54T5HO/UNV PSN HT	Program Rapid Start	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A
5	HI HOWARD INDUSTRIES	EP2/54HO/PRS/MV/W/MC	Programmed Rapid Start	2	N	N	Y	Y	N/A	N/A	N/A	N/A
6	ESPEN	VE254MVHRP 11101	Programmed Start	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A
7	ACT	ACT4M54PSUNV	Instant Start	4	Y	Y	Y	Y	Y	Y	Y	Y
8	ACT	ACT2S54PSUNV	Instant Start	2	N	N	Y	Y	N/A	N/A	N/A	N/A
9	OSRAM	QHE 4X54T5HO/UNV PSN HT SCL	Programmed Rapid Start	4	Y	Y	Y	Y	Y	Y	Y	Y
10	HI HOWARD INDUSTRIES	EP4/54HO/PRS/MV/L	Programmed Rapid Start	4	Y	Y	Y	Y	Y	Y	Y	Y
11	AccuStart	B454PUNVHB-E	Programmed Rapid Start	4	Y	Y	Y	Y	Y	Y	Y	Y
12	ESPEN	VE454MVHRP 11088	Programmed Start	4	Y	Y	Y	Y	Y	Y	Y	Y
13	FULHM RACEHORSE	RHA-UNV-454-LT5	Program Start	4	Y	Y	Y	Y	Y	Y	Y	Y
14	Plusrite	BAF454PS/MV	Program Start	4	Y	Y	Y	Y	Y	Y	Y	Y
15	FULHM RACEHORSE	RHA-UNV-254-LT5	Programmed Start	2	N	N	Y	Y	N/A	N/A	N/A	N/A
16	FULHM WORKHORSE	WH5-277-L	Instant Start	2	N/A	Y	N/A	Y	N/A	N/A	N/A	N/A
17	AccuStart	B254PUNV-D	Programmed Start	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A
18	PHILIPS ADVANCE	ICN-4S54-90C-2LS-G	Programmed Start	4	Y	Y	Y	Y	Y	Y	Y	Y
19	FULHM RACEHORSE	WH33-120-L	Instant Start	2	Y	N/A	Y	N/A	N/A	N/A	N/A	N/A
20	LEVITON	SD2J5-28M	Dimming Ballast	2	Y	Y	Y	Y	N/A	N/A	N/A	N/A

No.	Ballast Brand	Model No.	Start Type	Max Loading QTY	Compatible (Y/N/N/A)			
					1 LAMP	2 LAMPS	3 LAMPS	4 LAMPS
					347VAC	347VAC	347VAC	347VAC
1	PHILIPS ADVANCE	HCN-2S54-90C-WL	Instant Start	2	Y	Y	N/A	N/A
2	SYLVANIA	QTP 2X54T5HO/347-480 PSN HT	Programmed Start	2	Y	Y	N/A	N/A
3	GE	GE454PS347/480-E	Program Start	4	N	Y	Y	Y
4	Advance	HCN-4S54-90C-2LS-G	Programmed Start	4	Y	Y	Y	Y
5	GE	GE254PS347/480-F	Program Start	2	N	Y	N/A	N/A

No.	Ballast Brand	Model No.	Start Type	Max Loading QTY	Compatible (Y/N/N/A)			
					Charging		Emergency	
					120VAC	277VAC	120VAC	277VAC
1	IOTA	I-160	Emergency Ballast	2	Y	Y	Y	Y

Y: Compatible
N: Incompatible
N/A: Not applicable

When working with electronic ballast please check the compatibility list first!
If you couldn't find your ballast on the list then bypass the fixture, or contact us please!
Do not install the LED tube with the ballast which is not on the ballast compatibility list, risk of firing!